

2

Controlled release of biocides from encapsulation

Jeanette S-Eskesen jse@dti.dk

www.dti.dk

Danish Technological Institute





Danish Technological Institute



Expertise:

- Research and development projects in collaboration with university and industry
- Substitution and encapsulation
- Characterisation of particles



Focus:

- Sustainable materials
- Tailor-made material properties
- Substitution and reduction of problematical chemicals


Project: Encapsulated biocides

- Blue INNOship Partnership with approx. 40 partners
- 15 projects Activities for app. 16 million EUR

- Goals and objectives:
 - Control release rate of biocides in antifouling coating



DANISH TECHNOLOGICAL INSTITUTE





http://www.blaainno.dk/

Antifouling coating – Why and what for?



- Biocides are often used in antifouling coatings to prevent fouling
- Balance to have low toxicity and still prevent fouling




Antifouling coating – Why and what for?



- Fouling is unwanted biological growth on the underwater surface of marine vessels
- Increases drag on the surface:
 - Slime 1-2 %
 - Weed 10 %
 - Hard 40 %
- Benefits of AF coating:
 - Reduced waste emission, fuel, travel






Antifouling coating mechanism



DANISH


Release of biocides in antifouling coating






Benefits of using encapsulation in antifouling coating





Current status





Encapsulated zinc pyrithione




DANISH TECHNOLOGICAL INSTITUTE

Pure Zn-Pt






Silica



SEM-EDX of encapsulated zinc pyrithione






Load of encapsulated zinc pyrithione investigated from ICP-MS





	Average weight fraction (%) \pm STD
Zinc pyrithione	60±9
Silica	10±2
Silica + zinc pyrithione	70±11
Residual from synthesis	30±11



Incorporating encapsulated Zn-Pt into coating








Release experiments from coating film






Increased shell density



DANISH TECHNOLOGICAL INSTITUTE

Longer curing = More dense network




Increased shell thickness



DANISH TECHNOLOGICAL INSTITUTE


Silica:Zn-Pt 1:1

Silica:Zn-Pt 5:1



Release profiles from coating film II





Conclusions



- Succesful encapsulation of Zn-Pt
- Possible to alter thickness and density of silica capsules
- Succesful integration into antifouling coating
- No delayed release observed in tested antifouling coating

Acknowledgements



- Lars H. Jepsen, Gitte Tang Kristensen, Mikael Poulsen, and Jens Ravnsbæk, DTI
- Kim Flugt Soerensen and Stefan Olesen, Hempel A/S
- Blue InnoSHIP





Thank you for your time!

Jeanette S-Eskesen - jse@dti.dk Lars H. Jepsen – laje@dti.dk

www.dti.dk